
Meridian Administration Tools

MAT 5 Common Services

User guide

Document Number: P086759

Document Release: Standard 5.7

Date: October 1997

© 1994, 1996, 1997

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Document Revision history

Release Date	Document Version	Supported Release
October 1997	Standard	5.7
July 1997	Preliminary	5.7
February 1997	Preliminary	Pre-release 5.6
September 1996	Standard	5.01
September 1996	Standard	5.00
May 1996	Standard	4.0
February 1996	Preliminary	Pre-release 4.0 for field trials
November 1995	Preliminary	Pre-release 4.0 for testing
December 1994	Standard	2.0
June 1994	Standard	1.0

Contents

Introduction	1
Overview	1
MAT users	2
Conventions used in this manual	3
 Installing the MAT 5 Software	 5
Installing MAT on a Stand-alone PC	6
Installing MAT on the Server and First Client PC	9
Installing MAT on Additional Client PCs	12
Converting Data to MAT 5 Format	14
 Preparing for MAT 5 Installation	 15
Step 1: Check Meridian 1 Requirements	15
Step 2: Check PC Hardware and Software	18
Step 3: Prepare a Network Plan	19
Step 4: Set Up Windows95 Networking for MAT	20
Step 5: Setting Up the Communications Environment	27
Configuring PC Ethernet Communications	27
Configuring PC PPP Communications	27
Configuring PC Serial Communications	27
Step 6: Set Up the Meridian 1 for Ethernet and PPP	29
Configuring MAT Users on the Meridian 1	29
Configuring Ethernet and PPP at the Meridian 1	33
Connecting the PC to the Meridian 1	35
Testing Ethernet Connections	37
Testing PPP Connections	37
Step 7: Set Up a Network Environment	38
Step 8: Set Up the Server Environment	40
Setting Up a Windows NT Server	40

Setting Up a Netware Server	40
Validating the MAT Installation	41
Step 1: Login and Change the Default Password	41
Step 2: Set Up Communications Information	42
Step 3: Set Up Customer Information	46
Step 4: Set Up MAT Applications	47
Step 5: Set Up System Data Information	48
Step 6: Connect to the System	48
Configuring Sites, Systems, and Users	49
Changing the Default Login Password	49
Site and system administration	51
Adding a site	51
Adding a system	53
Changing site information	67
Changing system information	67
Deleting a site or system	68
Changing your password	69
Configuring MAT Users	70
Creating a User Template	70
Adding a User	72
Deleting a User Template	73
Restricting User Access Permission Levels	73
Sites and Systems Displayed in User Templates	73
Upgrading MAT 5 and Adding Licenses or Applications	75
Upgrading from an Earlier Version of MAT 5	75
Adding Applications or Licenses to a Stand-alone PC	77
Adding Applications or Licenses to Client PCs	79
Step 1: Add Applications or Licenses to First Client PC	79
Step 2: Add Applications or Licenses to Other Clients	79

MAT Navigator and System Window	81
Using the Navigator	82
Logging in and Launching the Navigator	82
Navigator Menus	85
Toolbar	89
Status Bar	89
Site and System Administration	90
Scheduler	90
Accessing the Scheduler	90
How the Scheduler works	91
Configuring & scheduling a job	93
Example job configuration	94
Device contention	95
File menu	97
Edit menu	97
Maintenance menu	98
Configuration menu	98
Queue Manager	98
Accessing the Queue Manager	99
Configuring a queue	100
System Window	100
System window menus	103
Toolbar	105
Responding to a connection failure	105
 System Terminal	 107
Launching System Terminal (Ethernet or PPP required)	108
System Terminal window	110
Using System Terminal	110
Advantages over a TTY	111
Getting help on the current overlay	111
Example	111
Getting help on the current prompt	112
Getting help on an error message	113

System Terminal Menus	114
Toolbar	117
Using the I/O Navigator	117
VT220	121
Features	121
Accessing VT220	122
File menu	124
Edit menu	124
Configuration menu	125
View menu	126
Terminal menu	127
Help Menu	137
Keyboard Mappings	128
PC Event Log	133
Using the PC Event window	133
Launching and using the PC Event window	133
Filter toolbar checkboxes	134
Learning more detail about an event	135
Appendix A: MAT 5 PC Requirements	137
Overview	137
Required PC Configuration	138
CPU	139
Memory Requirements	139
Examples of MAT 5 Virtual Memory Usage	140
Additional Packages	141
Memory Calculation Examples:	141
Hard drive requirements	143

Appendix B: MAT 5 Communications Requirements	145
X11 Releases Required for various MAT Applications	145
Systems equipped with IOP Cards	146
X11 Software Packages Required	146
Appendix C: Uninstalling MAT Software	147
Uninstalling MAT applications	147
Uninstalling MAT data	148
Appendix D: Script File Summary	149
Common Services scripts	149
Traffic Analysis scripts	150
Real time traffic data collection	150
Traffic data collection from MDR-2000	150
Traffic data collection from PollCat II	150
Traffic data collection from Site Event Buffer (SEB)	151
Traffic data collection from AT1/AT2	151
Traffic Analysis report generation	151
Call Accounting & Call Tracking scripts	152
Real time CDR data collection	153
CDR data collection from MDR-2000	153
CDR data collection from PollCat II	154
CDR data collection from Site Event Buffer (SEB)	154
CDR data collection from AT1/AT2	154
Call Tracking alarm scripts	154
CDR data collection modem scripts	155
Script usage table	155

**Appendix E: Modem Configuration Under
Windows®95 for MAT Applications 157**

High Speed Smart Modem Configuration Consideration 158

Troubleshooting Modem Connections 160